

## Round broach WI 26484

A14-020

The production process of this example tool contains full depth grinding of spline with the depth of 3.5mm and removal rate of 0.1mm per pass. Dressing in between cycles and certain finishing cycles are also necessary here.

The profile is made with profiled wheel which is calculated and dressed directly on the machine. The tool is clamped between centers, supported by steady rests and is driven by dog and driver.

This calculation includes also grinding of O.D. and resharpening time for serrations. Tooth alternation and division of teeth can be entered directly in Quinto software or probed by 3D probe on the machine.



Example broach of similar size on Corvus C360


### 1. Cycletime for Production

Workpiece: WI 26484				
Length: 1550mm; Diameter: 55.27mm; Nr. of splines: 17 Material HSS				
Operations	Probe	Flute 1	O.D.	Profiling
Feed [mm/Min]	3000	5	5	5000
Power [kW]		3	2	3
Cutting feed [m/s]		25	28	30
Used wheels				
Grinding time [min]	7	100	120	220
Total cycle time	7h 27min			

The cycle times are indicative. Material to be ground, grinding wheels, coolants can influence the cycle times considerably.

### 2. Used Grinding Wheels

1	14F1 Ø80 B91
2	Profiled 53A80 Ø250
3	1V1 70° B91



BBA only

### 3. Machine and Software Requirements

Machines: CNC grinders : Corvus BBA/ C360  
 Control: Fanuc 160i / 310i  
 Accessories: Dog and driver, Tailstock, Support, Magnetic plate  
 Responsible engineer: SIW, 02.2016

Coolant: Synthetic Oil, pressure 6 bar  
 Software: Quinto

www.schneeberger.ch  
 J. SCHNEEBERGER Maschinen AG 4914 Roggwil Switzerland  
 Subsidiaries in: France, Deutschland, Italia, United States, China

TECHNOLOGY  
FOR TOOLING